






80 ZL 1S BB Premium Box



Ersatzteil Nummer	Dimension
KUH.10578	815x500x16
KUH.10579	815x500x16
KUH.40027	767x485x16
KUH.90040	799x95x16
KUH.90401 x2	767x130x16











1	1	1	2	
4	2	2	2	4
+4.0x16mm	+3.5x13mm	+3.0x16mm	+4.0x25mm	17x17x15mm
4	12	8	2	1
+8x30mm	6,4 x 50mm			
8	8	8	2	4
		1	2	



ISM-KUH-02270

1

6.5x48x16	±8x30mm
	
F2	A
4	8




2

6,4 x 50mm



B

4







O

1




E1

4




3

6,4 x 50mm



B

4




O

1




E1




4



A diagram showing a T-joint assembly. A vertical rod is inserted into a horizontal rod. A screw, labeled 'P4', is shown being tightened into the horizontal rod. A screwdriver is shown to the right of the assembly, indicating the tool used for tightening the screw.



FRONT



			
11A	11J	11C	11E
1	1	1	2
			
11F	11G	11H	11I
4	2	2	2
4.0x16mm	3.5x13mm	3.0x16mm	4.0x25mm
			
P1	P5	P11	R
4	12	8	2
			
T17			
4			1