





SZAFKA

MIKA 150




11.02.2016

- (D) Montageanleitung
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (CZ) Montážní návod
- (HU) Szerelési útmutató
- (TR) Montaj talimatı
- (GB) Assembly Instructions
- (IT) Istruzioni di montaggio
- (PL) Instrukcja montażu
- (SK) Návod na montáž
- (RO) Instrucțiunile de montaj
- (RU) Инструкции по монтажу





2-2,5





1




M4 x2	C 4x12 x2	NC 4x16 x2	NG 5x16 x20	BS x2	D2 x2	RK x1	D x2	AS x1	I x2	J 4x25 x4
ZB x16	T x2	ND 3.5x16 x2	YD 7x50 x1	WB x2	ZG x1	ASG x1	R x3	ZC x3		
A 8x32 x8	SD x1	SG x1	W6 L-997mm x1	M 3.9x25 x2	HIM x2	S L-2042mm x1	N 3x20 x14			
X46	X1	X1	X20	X1	X20	X1	X8	X14	X4	X42



2






A 8x32
X12

YD 7x50
X4


WB X1

ZG X4

7



8




YD 7x50
X4

WB X1

ZG X4

9





YD 7x50
X12

WB X1


ZG X12

10




- X X8
- ZC X14
- S L-20x42mm X1
- N 3x20 X42
- ND 3.5x16 X6









11







- BS X2
- D2 X2
- R X2
- NG 5x16 X8
- NC 4x16 X10
- ND 3.5x16 X24






12



- D**  x2
- AS**  x1
- ASSG**  x1
- R**  x1
- RK**  x1
- NG**  5x16 **x8**
- NC**  4x16 **x10**
- ND**  3.5x16 **x24**



- SG**  x1
- W6** L-997mm  x1
- ND**  3.5x16 **x4**



- M4
X2
- C
4x12
X2
- M
3.9x25
X2
- HM
X2