






KORFU IV




- | | |
|--------------------------------|----------------------------|
| Ⓓ Montageanleitung | ⒼⒷ Assembly Instructions |
| ⒻⓇ Notice de montage | ⒾⓉ Istruzioni di montaggio |
| ⓃⓁ Handleiding voor de montage | ⓅⓁ Instrukcja montażu |
| ⒸⓏ Montážní návod | ⓈⓀ Návod na montáž |
| ⒽⓊ Szerelési útmutató | Ⓡⓞ Instrucțiuni de montaj |
| ⒹⓇ Montaj talimatı | ⓇⓊ Инструкции по монтажу |



1
2






3



x4



x4




x2


x2

5


4



x3



x3




x3




x3

6




7




9


8



10



11



12

