









SALSA

Typ 314






	2	4	1	4	2	2	24	24	24	10
10	6	2	4	24	10	16	4			








1





2




3















7




8



 E 24	 P11 6	 E2 16
 R2 4	 S11 2	 J5 4





SCHEMAT USTAWIENIA ZESTAWU